

SL6000 Series Manual

maxonic EUROPE LTD.

Maxon House, Cleveland Road,
Hemel Hempstead, Hertfordshire,
HP2 7EY, United Kingdom
Tel : +44 (0) 1442 267 777
Fax: +44 (0) 1442 215 515
Mail: sales@maxonic.co.uk
www.maxonic.co.uk



maxonic EUROPE LTD.

About Your SL6000 Radio

Maxon's SL6000 radio features up to 13 groups and up to 16 channel operation per group for a total channel capacity of 208 channels of superior performance and reliability. Operation and functions for Maxon's SL6000 radios are described in this manual.

We urge you to thoroughly read this manual before operating the radio. Application of some of the functions described in this manual is determined by the system you use.

Your Maxon Dealer will program your radio so that you have the greatest number of functions possible relative to your needs. Should you have questions regarding the operation of the radio please consult your Maxon Dealer.

SL6000 Specification

MODEL	SL6000 Series
MODEL CODE	7836
EQUIPMENT TYPE	Hand portable
PERFORMANCE SPECIFICATIONS	TIA/EIA-603/ETSI300.086
BAND	SL6102 VHF2(148~174Mhz) SL6402 UHF2(440~470Mhz)
CHANNEL SPACINGS	12.5KHz, 25KHz PROGRAMMABLE
RF OUTPUT POWER	5/1 WATT
MODULATION TYPE	F3E
AUDIO POWER	500mW (EXT WITH 16 OHM) 1W (INT WITH 4 OHM)
INTERMEDIATE FREQUENCY	45.1MHz 455KHz
CHANNELS	208 Channel
FREQUENCY SOURCE	SYNTHESIZER
POWER SUPPLY	:Li-ION(1750mA) 7.5 VDC NOMINAL EXTREME +/- 10% VDC EXTREME

Safety Information

– WARNING –

- DO NOT hold the radio in such a manner that the antenna is next to, or touching, exposed parts of the body, especially the face or eyes, while transmitting.
- DO NOT allow children to operate transmitter – equipped radio equipment.

– CAUTION –

- DO NOT operate the radio near unshielded electrical blasting caps or in an explosive atmosphere unless it is a type especially designed and qualified for such use.
- DO NOT press and hold the transmit switch (P-T-T) when not actually wishing to transmit.
- NEVER use the radio in an aircraft
- NEVER use the radio near to sensitive medical equipment or in areas where instructed, e.g. Petrol filling stations
- When used in a vehicle, do not mount the radio unit on or near the Airbag or Airbag activating device.
- The use of an accessory not recommended or supplied by Maxon may cause damage to equipment or injury to personnel, and will invalidate warranty.
- When using any of the charging accessories, the mains socket-outlet must be installed near the equipment.
- The outlet must not be obstructed and must be easily accessible at all times.
- Never attempt to disassemble, modify or repair the unit unless the work is carried out by a Maxon approved Reseller. Incorrect assembly, modification or repair may cause irreparable damage to your unit and will invalidate warranty. For service or repair always return your radio to an authorized Maxon Reseller.

Unpacking Information

Remove and carefully inspect the contents of your package(s) for the following items:


Radio
 Battery Pack
 Battery Charger
 Battery Charger Power Supply
 Antenna
 Spring Belt Clip
 User Manual

If any items are missing, please contact your dealer.

SL6000 Features

- Wideband frequency separation
- 1 or 5 W programmable output power
- Programmable 12.5/25 kHz channel spacing
- Channel scan
- Priority channel scan
- Look back channel
- CTCSS/DCS/DTMF tone signaling
- Busy channel lockout
- Time-out timer
- Scan List Edit
- Priority Channel Edit

Description of Radio Components




• Antenna Installation

Fasten the antenna to the radio by turning the antenna clockwise into the receptacle on top of the radio.

Installing and Removing the Battery Pack


- To Install:

Position the guides of the battery in line with the radio battery guide rails and slide the battery into position until a "click" is heard.



- To Remove:

Holding radio in one hand, push and hold battery latch button located in the bottom of the set. Using the other hand, slide the battery in a downward direction while pushing the battery latch button.



Attaching and Removing the Belt Clip

- To Install:

Install belt clip onto the slot located on the upper middle of the radio, held as if looking at the back of the unit. Locate the belt clip and align with the slot and down belt clip until a click is heard.

- To Remove:

Push and hold release button located at top of belt clip and slide clip off the belt clip holder.

Battery Charging and Care

To ensure peak performance from your radio, the battery pack must be fully charged. Proper care and charging will allow maximum performance and life of your battery pack. CH6000-02 Desktop Charger provides 2 hours charging to one radio and one spare battery. To receive maximum performance from your radio and battery pack, periodically completely discharge and recharge the battery pack.

Indicators and Tones(Title)

Your SL6000 has a sophisticated microprocessor control which provides a series of audible alert tones.

Upon initial power up, a quick melody indicates that the self-test of the microprocessor functions has been completed satisfactorily. A series of tones may be sounded with any of the following conditions:

- Attempt to transmit on a channel set for receive only
- Attempt to transmit on a channel that is already in use when busy channel lockout has been programmed into the radio *
- Transmitting time has exceeded time-out timer programmed length *
- Low battery condition
- Selecting a channel with no programmed frequency

- * Indicates a function that is initially programmed into the radio by your Maxon Dealer.

NOTE: All audible tones can be programmed off for silent operation.

Status	Description	LED color	LCD Indication	Audible Tone
Normal	Power On — Ready	N/A	Channel number	Melody
	Call Received	Orange	Channel number	N/A
	Correct Call	Green	Channel number	N/A
	Busy Channel	Orange	Channel number	N/A
	Transmit	Red	Channel number	N/A
	Transmit not allowed	Red Flashing	Alternating UL/ Channel number	Two beeps repeated
Scanning	Normal Scan mode	Green Flashing	Group number	N/A
	Priority Scan Mode	Green Flashing		
Scan Edit	Edit scan list	N/A	Scan	N/A
Priority Edit	Edit Priority channel	N/A	Pscn	N/A
Warning	Low Battery	Red Flashing	Low—BATT	3 beeps repeated
	Busy Channel lockout	orange	Busy—Lock	Single beep repeated
	TX Inhibit	N/A	PENALTY	Two beeps repeated
	Time—out—timer	N/A	TIME—OUT	Single beep/3 beeps repeated
Error	Unlock	N/A	UNLOCK	Two beeps repeated

Operation Mode

This section provides general descriptions of the operating modes of the SL6000 Radio.

Power Off Mode

The SL6000 shall enter Off mode when the On/Off Volume knob is rotated to the most counter—clockwise position, beyond the detent. Upon entering Off mode, the radio shall store its current channel (if Power On Channel function is disabled via PC programmer).

Power On Mode

The SL6000 shall enter Power—On mode when the On/Off Volume knob is rotated clockwise beyond the detent. Upon entry of the Power—On mode, the radio shall perform the 5 times power—on alert to indicate that it has been turned on.

Menu Button

You can enter the menu mode by pressing 2 seconds more menu/scan button. It is possible to enable/disable or change options like below in menu mode. beep (on/off), DTMF (on/off), password (on/off), VOX (on/off), squelch level (1~10), VOX level (1~9), VOX delay time (1~6).

VOX (Voice operated transmit)

This is the function that the radio can transmit by voice without pressing the PTT key. The radio can transmit with low and high voice in accordance with VOX level 1~9.

VOX delay level 1~6 decide continue or stop how many transmit time when the TX is finished.

This function set as pc program or menu mode.

High / Low Power

The radio shall be capable of programmable output power. Each channel can be programmed via pc programmer to have either high or low power. Or it is set by pressing G/H/L button, then display H or L icon.

Cloning

Frequencies and functions can be programmed from radio to radio by using a cloning cable.

Lamp

This function can be operate whenever press the lamp/Lock button. LCD and Keypad Back Lighting on/off is toggled whenever press the lamp/lock button.

After backlight is ON, it will be Off automatically in 10 seconds.

Key Lock

This function can disable all keys except PTT, Monitor, Lamp, Emergency Key. This function is set when holding the Lamp. Lock button 2 seconds or more and padlock icon is displayed. Lock function is not disabled although power off and then power on again. To disable Lock function, press the Lamp/Lock button again 2secs or more.

Battery Indicator

It displays charging level of battery. (1~7) Upon detection of low battery condition, the radio shall emit three beeps repeatedly with display message "LOW-BATT". Radio continuously flashes the red LED for the duration of 500ms to indicate a low battery condition, the radio shall transmit the audio.

If low battery, the radio can transmit continuously but out power is only low power and then low battery alert shall be given and displayed

Squelch Level

This function enables speaker when the receiving signal level is more than selected level and disable speaker when it is less than selected level. You can set this option at PC Program or SQ level item in menu mode.

In menu mode case, display "SQLv + number" and you can select 1~10 as up/dn button.

Group Button

SL6000 radio can use maximum 13 groups. Each group has maximum 16 channels and one priority channel. The group that you want can be set by PC program. If a group set, display current group number at left side below on LCD. In group mode you can edit scan list channel and priority channel with your own hands with the radio. Press the TX power/group button 2 secs or more, then display "GRP" on left side LCD bottom. At this time you can move to the group you want by using up/dn button. When display the group button, you can exit this function with pressing PTT.

Password

Password function is the function that the user knows the password can use the radio.

You can set password enable and the password code at pc program. And you can set password enable/disable by programmable key (password and menu option). Display "0000" on LCD and "?" at currently place that you can enter the password code. At this time you can enter the password code by using Up/Dn button. To move next place, press PTT key. When you press the PTT key at the last 4th place after enter the all code, if the code is not correct, and then display "0000" again. To disable password function, you can select On/Off by using Menu or programmable key (password option). If you enable password at the Menu Mode of the radio programmed without password, then default password code set "1234"

Icon



	<Transmitting Icon > * Hi power: Antenna bar is full. * Low power :Antenna bar is 3.
	<Receiving Icon> Change antenna bar 0~5 by receiving signal sense.
P/L	P : current channel is priority channel. L : current channel is lookback channel.
VX	VOX
S	Current channel is scan channel
T	Current channel has a sub tone.
H/L	H : TX power is high L : TX power is low.
GRP	This icon is displayed if there is a group.
	Display when DTMF is set.
	Display when Beep is on.
	Display when Key Lock option is on.
	Display charging level of battery.

Menu / Scan Button

- ① Pressing the Menu/Scan Key : scan operating
- ② Pressing the Menu/Scan Key 2 seconds or more : enter the menu mode

Channel UP / DOWN

- ① Normal : Select a channel.
- ② Menu Mode : On/Off or change Option in the Menu mode.
- ③ Password : Channel UP/DOWN.

GRP / PWR Button

- ① Short Pressing : Select POWER LOW / HIGH.
- ② Long Pressing : GROUP MODE .
(GROUP selecting use CH UP / DOWN KEY)
- ③ PASSWORD : Move the cursor to prev/next digit.

LAMP / LOCK Button

- ① Short pressing : LAMP and Back Light ON / OFF
- ② Long pressing : KEY LOCK
*You can use PTT, Monitor, EMG, Lamp/Lock Key only

PTT Button

- ① Press and Hold to transmit. Release to receive mode.
- ② Power on with press and holding PTT Key to see software version.

MONITOR Button

Release squelch and tone circuit to check whether you can use or not current channel.

EMG Button

- ① Transmit DTMF ID 3 times and generate warning audio alert during 5 seconds.

Squelch Options

The radio shall support three different squelch options: CTCSS, DCS, Squelch defeat (Monitor). Each channel shall have its squelch option set during dealer programming. For each transmit operation, the squelch option shall be implemented if the channel is deemed not busy.

CTCSS

The radio shall support the 47 CTCSS tones and non-standard CTCSS tones ranging from 50Hz to 300Hz in 0.1Hz increments. All the tones shall be set up during dealer programming.

- TX operation : Upon pressing PTT, the radio shall encode the channel's programmed CTCSS tone and enter TX mode. The tone shall last for the duration of the transmission.
- End of TX operation : Upon leaving TX mode, the radio may employ dealer programmable squelch tail elimination functions.
- RX operation : When the proper CTCSS tone is decoded, the radio shall enter correct call state from busy state. When the proper CTCSS tone is no longer being decoded, the radio shall enter busy state from correct call state.

DCS

The Radio shall support the encoding and decoding of 83 normal and inverted DCS data.

- TX operation : Upon the pressing of PTT, the radio shall encode the programmed DCS bit pattern for the selected channel and enter TX mode. The data shall last for the duration of the transmission.
- End of TX operation : Upon leaving TX mode, the radio may employ squelch tail elimination. This shall be done by sending a turn off code.
- RX operation : The radio shall decode the incoming data stream to determine if there is a match with the pre-programmed DCS data. If the DCS data is properly decoded, the radio shall enter correct call state from busy state. When the proper DCS data is no longer being decoded, the radio shall enter busy state from correct call state.

Scan Modes

Scanning is a dealer programmable feature that allows you to monitor a number of channels or channels within a group. Your dealer will help you define channel "scan list".

Normal Channel Scan

During programming of the radio, any channel can be selected as a scanned channel. The scan list will be activated by switching to the channel that was selected as the scan list channel during programming of the system parameters. The user shall activate scanning by selecting the scanned channel for current channel. While the radio is scanning, the LED shall flash green as the radio scans. Once the radio has enabled scan, the radio shall traverse through the pre-programmed scan list. The time spent on receiving a channel in the scan list is referred to as the scan speed time. When an incoming call is detected and decoded, scanning shall stop and the radio shall enter Un-muted Busy Mode or Correct Call Mode. After the call has ended, the radio shall enter Un-muted Busy Mode or Correct Call Mode for a pre-programmed period of scan wait time. If the radio receives a call from the same caller before the scan wait time expires, the radio shall re-enter Un-muted Busy Mode or Correct Call Mode and the scan wait time shall be reset. If the user is permitted to respond to the caller, the scan wait time shall be reset. When the scan wait time expires, the radio shall resume scanning.

Priority Channel Scan

This scan function can be set by PC program option. This function operates only when priority channel is set. If radio has not a priority channel, this function not work although radio has scan channels. SL6000 Radio scan which receiving signal or not at priority channel between scan channel and scan channel during scanning each scan channel. If you try to TX on priority scanning, SL6000 radio transmits according to TX option by PC Program. Green led blinks also. Press the scan button or up/dn button to exit this function.

Other Scanning Features

• Look Back

This function makes the radio scanning between priority channel and lookback channel. When the current channel is the look back channel, The PriorityLook back Scan will auto_start. Scan channel is only 2 channel (current lookback channel and priority channel). Lookback channel is displayed "L" on LCD. The lookback channel can be set by PC Program. Other function is the same normal scan function.

• Scan Channel Delete:

To temporarily delete a channel from the scan list, simply press the G/H/L button while scanning and stopped on the channel to be deleted. This will remove that channel from the scan list until the channel is changed or the radio's power is reset. When power is restored or the scan list channel position is again selected, the original Dealer programmed scan list will be activated.

TX on Scan Mode**• Normal Scan TX:**

Allows a transmission only after a call is received, depending on the programmed scan delay time. After the scan resumes, and a transmission is made, the radio will sound an alarm (two beeps), display TX Inhibit and will not allow a transmission.

• Priority Scan TX:

Allows a transmission after a call is received depending on programmed scan delay time. The transmission will be made on the channel that the call was received. After the scan resumes, if a transmission is made, the radio will transmit on the programmed priority channel.

• Priority Only TX:

Allows a transmission on the priority channel when scanning and not stopped on an active channel. It always transmit on the priority channel if scanning or stopped on an active channel.

• Receive Only TX:

This allows only reception. If a transmission is made at any time, the radio will sound an alarm (two beeps), display TX inhibit and will not allow the transmission.

Scan/Priority Channel Edit**• Scan Channel List Edit**

This function is editable and displayed when the radio sets up the group scan. You can edit your pre-programmed Group Scan List by adding or deleting scan list from the Group Scan List. To activate scan list editing, press the Menu button until the radio enters 'Scan List Edit Mode'.

Upon entering 'the Scan List Edit Mode', the LCD will indicate the 'ScnL' message. To exit the scan list edit function, Press the PTT.

The radio will display the scan channel number by 'S' Icon On or Off. You can change the scan channel by up or down button. To add or delete this channel from the scan list, press the monitor button. When added, the 'S' Icon will display on the LCD display window. When deleted, the 'S' Icon will disappear on the LCD display window.

• Priority Channel Edit

This function is editable and displayed when the radio sets up the group scan. To activate Priority channel editing, press the Menu/Scan button until the radio enters 'Priority channel Edit Mode'. Upon entering 'the Priority channel Edit Mode', the LCD will indicate the 'Pscn' message. To exit the Priority channel edit function, Press the PTT. The radio will display the Priority channel number by 'P' Icon On or Off.

You can change the Priority channel by up or down button. To change the priority channel, press the monitor button. If selected the priority channel, the 'P' Icon will display on the LCD display window. When deleted, the 'P' Icon will disappear on the LCD display window.

The Priority channel is only one setting up the each group. If pressed the monitor button, Current Channel is changed the Priority channel and then previous priority channel is deleted. if the look back channel is setting up in the current Group, it can not deleted the Priority channel and the Look back channel is not changed the Priority channel

Service Information

Service

Do not tamper with internal adjustments, damage to the equipment and/or improper operation may result.

There are no user serviceable items inside the radio.

It is recommended that you return your radio to a qualified Maxon dealer for any service or repairs.

Recycling/Disposal of Batteries

The battery should be recycled at the end of its useful life. Under various state or local laws, such batteries must be recycled or disposed of properly and cannot be dumped in landfills or incinerators.

For further information on how to safely dispose of four used batteries, contact your reseller.

Maintenance

Your SL6000 Radio is designed to be maintenance free.

To keep your radio in good working condition:

Clean external surfaces with a clean cloth dampened in a solution of dishwasher detergent diluted in water.

Apply the solution sparingly to avoid any moisture leaking into cracks and crevices. Do not submerge the radio.

Use a non-metallic brush to dislodge stubborn particles, if necessary. Dry the surface thoroughly with a soft, lint free cloth.

DO NOT use solvents or spirits for cleaning – they may permanently damage the housing.

Clean the battery contacts on the back of the radio with a lint free cloth to remove dirt, grease, or other foreign material that may impede good electrical contact.

Limited Warranty

Maxon shall have no obligation to make repairs or to cause replacement required which result from normal wear and tear or necessitated in whole or in part by catastrophe, fault or negligence of the user, improper or unauthorized alterations, repairs to the Product, use of the Product in a manner for which it was not designed, or by causes external to the Product. This warranty is void if the serial number is altered, defaced or removed.

Maxon's sole obligation hereunder shall be to repair or replace the Product covered in the above warranty.

DECLARATION OF CONFORMITY

We,  EUROPE LTD.

of Maxon House
Cleveland Road
Hemel Hempstead
Herts, HP2 7EY
United Kingdom

declare under our sole responsibility, as the EU authorised representative, that the products:

SL6102 VHF

manufactured by Maxon to which this declaration relates are in conformity with the following standards and/or other normative documents.

Essential Requirement	Specification/Standards	Documentation Evidence
Art. 3.1 (a) Health	Council Rec. 99/519/EC	Declaration of Conformity
Art. 3.1 (a) Safety	EN 60950-1	Test Report STR-07-0087 S R LV
Art. 3.1 (b) EMC	EN 301 489-1 V1.6.1:2005 EN 301 489-5 V1.3.1:2002	Test Report STK-07-EMOG0304
Art. 3.2 Radio	EN 300 086-2 V1.1.1 (2001-03)	Test Report STROR-07-097-R2

We hereby declare that all essential radio test suites have been carried out and that the above named products are in conformity to all the essential requirements of Directive 1999/5/EC.

The conformity assessment procedure referred to in Article 10(5) and detailed in Annex IV of Directive 1999/5/EC has been followed with the involvement of the following Notified Body:


EMCCert DR, RASEK GmbH, Moggast, Boelwiese 5, 91320 Ebermannstadt, Germany

Identification mark: 0678

The equipment will also carry the  Class 2 equipment identifier

The technical documentation relevant to the above equipment can be made available for inspection on application to:

Maxon IC Europe Ltd
Maxon House
Cleveland Road
Hemel Hempstead
Herts, HP2 7EY
United Kingdom



HYO DONG HAN
Managing Director

December 2007

SL6102 VHF

This product is marked with

CE0678 

in accordance with the Class II product requirements specified in the R&TTE Directive, 1999/5/EC

"We hereby declare that the above named product is in conformity to all the essential requirements of Directive 1999/5/EC".

This equipment is intended for use in:-

Austria, Belgium, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Poland, Portugal, Slovakia, Slovenia, Spain, Sweden, United Kingdom, Iceland, Liechtenstein, Norway, Switzerland, Bulgaria, Romania & Turkey.

and requires authorisation (individual licence) for use.

We hereby declare that the above named product is in conformity to all the essential requirements of Directive 1999/5/EC.

Wir möchten hiermit bekanntgeben, daß das oben genannte Produkt in Übereinstimmung mit allen erforderlichen Bedürfnissen der 1999/5/EC Direktive steht

Certificamos que el aparato es conforme con lo establecido en las disposiciones de la Directiva 1999/5/CE.

Nous déclarons que le produit référencé ci-dessus satisfait aux exigences R&TTE 1999/5/EC qui lui sont applicables.